



# BUILDER'S LEGACY

## ProSpec DRYWALL PRIMER 1053

PERFORMANCE SERIES  
INTERIOR  
PRIMER  
1053  
PROSPEC DRYWALL PRIMER

**PROSPEC DRYWALL PRIMER** is a production grade primer designed to prepare new drywall for painting and texturing. The high-building nature fills exceptionally well producing uniform porosity with good enamel hold-out for improved finish coat performance. When sprayed for full coverage, it will provide good wet and dry hide while helping reduce telegraphing seams and picture framing.

**PROSPEC DRYWALL PRIMER** is designed for the high production, value-driven new construction market. The zero-VOC, LEED v4 compliant formula reduces air quality impact on fellow trades while meeting strict air quality standards. Best suited for residential and commercial production markets and topcoated with Builder's Legacy and Pro Kote interior finishes.

### COMPLIANCE & CERTIFICATION

Gloss Level	1
VOC Content	< 5 g/L < 0.042 lb./Gal
LEED v4 Credit Eligible	YES

### RECOMMENDED USAGE

- For interior use only.
- Ideal for residential, multi-family, commercial, and mixed-use projects.
- Ideal for priming prior to texture and/or under flat, matte, or lo-sheen finishes.

### PERFORMANCE & FEATURES

- Production-Focused Design
- Creates Uniform Surface Porosity
- Hi-Building Film
- Zero-VOC, LEED v4 Credit Eligible

### BENEFITS

**Production-Focused Design:** Fast spraying design fills and seals drywall with a single coat for faster job completion.

**Hi-Building Properties:** Robust formulation allows for greater film-build with lower risk of mud-cracking.

**Low-Odor, Zero-VOC Formulation:** This zero-VOC, LEED v4 Credit Eligible finish provides the performance needed for contractors, specifiers, and general contractors looking to meet the strictest air quality standards.

### PRODUCT SPECIFICATIONS

**Vehicle Type:** Ethylene-Vinyl Acetate

**Color Tinting:** Toned White. May be tinted, up to 2 oz. per gallon, with low VOC colorants.

**Gloss:** Flat 1-3 units @ 60°

1-3 units @ 85°

**Solid Content:** Volume: 31% ± 2

**Drying Time:** (75° F. & 50% R.H.)

To touch: 1 Hour

To recoat: 2-4 Hours

*Extended drying time may be expected when conditions such as high humidity, high dew point, low temperature, etc. are present. Allow product to dry thoroughly before top coating*

### Theoretical Coverage:

Apply at 200-250 sq. ft./gal.

*When calculating working coverage, allow for application losses, texture and porosity of surface, application technique, etc.*

### PRECAUTIONS/LIMITATIONS

- Please refer to Safety Data Sheets.
- Apply only if air, surface and material temperatures remain 50° F or above during application and drying.
- Not for use on floors.
- Protect from freezing.



# BUILDER'S LEGACY

## **ProSpec** DRYWALL PRIMER 1053

PERFORMANCE SERIES  
INTERIOR  
PRIMER  
1053  
PROSPEC DRYWALL PRIMER

### **SURFACE PREPARATION**

Surfaces must be dry, clean and free of dust, dirt, grease, oil or any other contaminants that may prevent proper adhesion. All loose paint must be removed and glossy surfaces dulled by sanding. Plaster surfaces must be well cured, and porous masonry surfaces should be filled with block filler. Tape joints and nailheads on drywall should be sanded and dusted clean before finishing. Mud on joints and nailheads must be thoroughly cured before finishing to help avoid photographing.

**Warning! If you scrape, sand or remove old paint, you may release lead dust. Lead is toxic. Exposure to lead dust can cause serious illness, such as brain damage, especially in children. Pregnant women should also avoid exposure. Wear a NIOSH-approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the national lead information hotline at 1-800-424-LEAD (5323) or log on to [www.epa.gov/lead](http://www.epa.gov/lead).**

### **HALLMAN LINDSAY FINISH RECOMMENDATIONS**

**Professional Finish:** PRO KOTE and RENEWAL Series

**Builder's Legacy Finishes:** MASTER KOTE, VELVET ARMOR, and PREMIUM SMOOTH HI-BUILD Series.

### **APPLICATION**

Mix thoroughly before use. Apply by brush, roller, or airless spray or conventional spray. Flow and leveling is best achieved by applying a full, uniform coating and working to a wet edge using overlapping strokes. Do not brush or roll excessively. Surfaces should be dry prior to paint application. Reducing material for spray application should not exceed 10%. All products are formulated ready for application. If needed, thin sparingly and do not exceed 2oz per gallon. Clean all applicators with water immediately after use.

### **EQUIPMENT REQUIREMENTS**

**Airless:** Minimum .70 GPM, 2800 PSI, .019-.023" Tip

**HVLP:** Not Recommended

**Roller:** 1/2" - 3/4" Nap Shed-resistant or Lambswool Cover

**Brush:** 100% Nylon or Synthetic Blend