



# BUILDER'S LEGACY

## PVA DRYWALL PRIMER/SEALER

### 229

PERFORMANCE SERIES  
INTERIOR  
PRIME COAT  
229  
PVA DRYWALL PRIMER/SEALER

Builder's Legacy PVA Primer/Sealer is designed specially for use on drywall in the new construction market. Formulated for fast and efficient spray application, this primer/sealer can be used on drywall, concrete, and cured plaster. It produces a smooth, uniform surface ready for paint or texturing.

Builder's Legacy PVA Primer/Sealer is a professional-grade first coat designed for high-production applications. Low-odor, zero-VOC formulation helps meet the strictest air-quality standards. Use on a variety of projects including residential new construction and remodeling, multifamily, and other new construction commercial projects.

#### COMPLIANCE & CERTIFICATION

Gloss Level	1
VOC Content	< 5 g/L < 0.04 lb./Gal
LEED v4 Credit Eligible	YES

#### RECOMMENDED USAGE

- For interior new drywall.
- Primer/sealer for lower sheen finishes.
- Use in residential, commercial, and institutional new construction.

#### PERFORMANCE & FEATURES

- Professional-focused primer
- Good enamel hold-out
- Fast-drying formula
- Zero-VOC, LEED v4 credit eligible

#### BENEFITS

**Professional Focus:** This primer/sealer is formulated for fast and efficient spray application.

**Better Foundation:** PVA Primer/Sealer provides an improved foundation for better enamel hold-out over conventional primers.

**Environmentally Responsible Product:** This zero-VOC, LEED v4 Credit Eligible finish meets the performance needs of contractors, specifiers, and general contractors looking to meet the strictest air quality standards.

#### PRODUCT SPECIFICATIONS

**Vehicle Type:** Modified vinyl acrylic.

**Color Tinting:** White.

**Gloss:** Flat. 1-4 units @ 60°

**Solid Content:** Weight: 30% ± 2  
Volume: 19% ± 2

**Drying Time:** (75° F. & 50% R.H.)

To touch: 1 Hour

To recoat: 2 Hours

*Extended drying time may be expected when conditions such as high humidity, high dew point, low temperature, etc. are present. Allow product to dry thoroughly before top coating*

#### Theoretical Coverage:

Apply at 400 sq. ft./gal. to achieve  
4.0 mils Wet Film Thickness  
0.8 mils Dry Film Thickness

*When calculating working coverage, allow for application losses, texture and porosity of surface, application technique, etc.*

#### PRECAUTIONS/LIMITATIONS

- Please refer to Safety Data Sheets.
- For use under flat, lo-sheen, and eggshell finishes only.
- Do not apply to uncured plaster.
- Apply only if surface and paint temperatures are above 50° F and will remain so for 48 hours. Dew point must not be within 5° of the temperature until film is dry.



# BUILDER'S LEGACY

## PVA DRYWALL PRIMER/SEALER 229

PERFORMANCE SERIES  
INTERIOR  
PRIME COAT  
229  
PVA DRYWALL PRIMER/SEALER

### SURFACE PREPARATION

On drywall, all taped joints and nail heads should be sanded smooth and dusted. Patch all holes and cracks with an appropriate patching compound. Let dry thoroughly, sand smooth, and prime. Surfaces must be dry, clean, and free of dirt, oil, or any other contaminants.

**Warning! If you scrape, sand or remove old paint, you may release lead dust. Lead is toxic. Exposure to lead dust can cause serious illness, such as brain damage, especially in children. Pregnant women should also avoid exposure. Wear a NIOSH-approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the national lead information hotline at 1-800-424-LEAD (5323) or log on to [www.epa.gov/lead](http://www.epa.gov/lead).**

### HALLMAN LINDSAY FINISHING RECOMMENDATIONS

**Premium finish:** Wonder Kote and Earthscapes series.

**Professional finish:** Pro Kote and Renewal series.

**Builder's Legacy finishes:** Master Kote, Velvet Armor, and Premium Smooth Hi-Build series.

### APPLICATION

Mix thoroughly before use. Best suited for airless spray application but can also be applied by brush and roll. Flow, leveling, and performance qualities are best achieved by applying a full, uniform coating and working to a wet edge using overlapping strokes. Reducing material for spray application should not exceed 10%. Apply when air, surface and material temperatures above 50°F. Clean all applicators with water immediately after use.

### EQUIPMENT REQUIREMENTS

**Airless:** Minimum .45 GPM, 2800 PSI, .015 - .019" Tip

**HVLP:** Twin-stage turbine, 5-8 PSI, .051 to .070 projector set

**Roller:** 1/4" - 1/2" nap shed-resistant cover or lambswool cover

**Brush:** 100% Nylon or Synthetic Blend