



# WONDERKOTE

## SEMI-GLOSS INTERIOR LATEX WALL FINISH

### 295

PREMIUM SERIES  
INTERIOR  
SEMI-GLOSS  
295  
WONDERKOTE

WONDERKOTE interior latex delivers the perfect balance between long-lasting beauty and fast, easy application that professionals have trusted for decades. High-hiding formula provides exceptional coverage and seamless touch-up for fast, easy color changes and job completion. The durable and washable finish repels stains, scuffs, and other signs of everyday living for lasting beauty and protection.

WONDERKOTE is our premium line of interior low-VOC finishes designed for consistent results with custom painting projects. These products can be applied to a variety of surfaces including drywall, plaster, and previously painted surfaces. They can be applied as a premium upgrade in new construction projects or as a workhorse line for residential and commercial repainting projects.

#### COMPLIANCE & CERTIFICATION

Gloss Level	4
VOC Content	117 g/L 0.98 lb./Gal

#### RECOMMENDED USAGE

- For Interior Use
- Drywall, Plaster, Wallboard, and Similar Surfaces
- Maintenance and New Construction

#### PERFORMANCE & FEATURES

- Easy Custom Color Changes
- Livable & Lasting Finish
- Great Durability
- Reliable Performance
- Can Help meet LEED v4 Credits

#### BENEFITS

**Maintenance Friendly Finish:** Premium formula allows most stains to easily wipe off and release with soap and water. Seamlessly touchup stubborn stains, dings, and scuffs.

**Reliable Coverage:** Improved hide reduces the number of coats and time spent cutting compared to typical professional finishes.

**Easy Application:** Enjoy consistent, user-friendly application where paint glides off the brush and roller providing a nice, uniform sheen with good touch-up qualities.

#### PRODUCT SPECIFICATIONS

**Vehicle Type:** Ethylene-Vinyl Acetate / Acrylic

**Color Tinting:** White and Tint Bases

**Gloss:** Semi-Gloss  
35-50 units @ 60°

**Solid Content:** Weight: 44% ± 2  
Volume: 34% ± 2

**Drying Time:** (75° F. & 50% R.H.)  
To touch: 1 Hour  
To recoat: 4 Hours

*Extended drying time may be expected when conditions such as high humidity, high dew point, low temperature, etc. are present. Allow product to dry thoroughly before top coating*

#### **Theoretical Coverage:**

Apply at 400 sq. ft./gal. to achieve  
4.0 mils Wet Film Thickness  
1.6 mils Dry Film Thickness

*When calculating working coverage, allow for application losses, texture and porosity of surface, application technique, etc.*

#### PRECAUTIONS/LIMITATIONS

- Please refer to Safety Data Sheets.
- Apply only if air, surface and material temperatures remain 50° F or above during application and drying.



# WONDERKOTE

## SEMI-GLOSS INTERIOR LATEX WALL FINISH

### 295

PREMIUM SERIES  
INTERIOR  
SEMI-GLOSS  
295  
WONDERKOTE

### SURFACE PREPARATION

Surfaces must be dry, clean and free of dust, dirt, grease, oil or any other contaminants that may prevent proper adhesion. All loose paint must be removed and glossy surfaces dulled by sanding. Plaster surfaces must be well cured, and porous masonry surfaces should be filled with block filler. Tape joints and nailheads on drywall should be sanded and dusted clean before finishing. Mud on joints and nailheads must be thoroughly cured before finishing to help avoid photographing. Galvanized surfaces shall have all oils removed prior to application of coating.

**Warning!** If you scrape, sand or remove old paint, you may release lead dust. Lead is toxic. Exposure to lead dust can cause serious illness, such as brain damage, especially in children. Pregnant women should also avoid exposure. Wear a NIOSH-approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the national lead information hotline at 1-800-424-LEAD (5323) or log on to [www.epa.gov/lead](http://www.epa.gov/lead).

### HALLMAN LINDSAY PRIMING RECOMMENDATIONS

#### **New Work**

**Drywall:** Premium Wall Primer, 220.

**Plaster/Masonry:** GRIPCRETE Masonry/Plaster Primer, 166.

**Wood:** Enamel Undercoat, 231.

**Galvanized Surfaces:** Enamel Undercoat, 231, METALGUARD ACRYLIC DTM Primer/Finish, 338.

**Steel Surfaces:** METALGUARD Rust Inhibitive Primer, 330

**Block:** GRIPCRETE HD Block Filler, 181.

**Repaint:** Self-Priming (requires two coats).

### APPLICATION

Mix thoroughly before use. Apply by brush, roller, or airless spray or conventional spray. Flow and leveling is best achieved by applying a full, uniform coating and working to a wet edge using overlapping strokes. Do not brush or roll excessively. Surfaces should be dry prior to paint application. Reducing material for spray application should not exceed 10%. All products are formulated ready for application. If needed, thin sparingly and do not exceed 2oz per gallon. Clean all applicators with water immediately after use.

### EQUIPMENT REQUIREMENTS

**Airless:** Minimum .70 GPM, 2500 PSI, .017-.019" Tip

**HVLP:** Twin-stage turbine, 5-8 PSI, .051 to .070 projector set

**Roller:** 1/2" - 3/4" nap synthetic cover

**Brush:** 100% Nylon or Synthetic Blend