



# CLEARGUARD

## SATIN INTERIOR WB FLOOR REFINISHER

### V365

DESIGNER SERIES  
INTERIOR  
SATIN  
V365  
CLEARGUARD WB  
FLOOR FINISH

CLEARGUARD WATERBORNE URETHANE is a premium oil-modified urethane clear wood finish. This floor-rated finish has exceptional flow and leveling helping to provide a smooth, blemish-free coating on wood floors, trim, doors and all other interior wood surfaces.

The oil-modified resin provides a durable finish with a slight amber cast for a warm, natural wood appearance. Strong resistance to water, oil, household chemicals, and abrasion provides long-lasting protection and beauty. CLEARGUARD WATERBORNE URETHANE is designed to provide a durable, clear wood finish to a variety of wood surfaces in an easy-application formula. Use it on any surface where durability is required, such as sports floors, multi-purpose gyms, studios, and heavy traffic residential and commercial areas. Can be applied using a variety of applications including brush, roller, pad, squeegee, and weighted T-bar.

### COMPLIANCE & CERTIFICATION

Gloss Level	4
VOC Content	178 g/L 1.49 lb./Gal

### RECOMMENDED USAGE

- For Interior Use
- Sports Floors, Multi-Purpose Gyms, and Studios
- Heavy Traffic Residential and Commercial areas.

### PERFORMANCE & FEATURES

- Fast Recoat Times
- Clear, Natural Amber Finish
- Floor-Rated Urethane
- Excellent Flow & Leveling

### BENEFITS

**Waterborne Urethane Technology:** Improve air quality and performance by providing the classic amber toning of alkyd products with the clean-up, VOC's, and low odor of a waterborne finish.

**Smooth, Uniform Finish:** Self-leveling technology helps reduce lap lines, roller stipple, and brush strokes to provide a smooth, seamless finish.

**Fast Return to Service:** Quick dry times allow for multiple coats to be applied in the same day minimizing down time for a faster return to service.

### PRODUCT SPECIFICATIONS

**Vehicle Type:** Oil Modified Urethane Dispersion

**Color Tinting:** Natural Amber Clear Finish

**Gloss:** Satin

25-30 units @ 60°

**Solid Content:** Weight: 33% ± 2

Volume: 29% ± 2

**Drying Time:** (75° F. & 50% R.H.)

To touch: 1 Hour

To recoat: 3 Hours

*Extended drying time may be expected when conditions such as high humidity, high dew point, low temperature, etc. are present. Allow product to dry thoroughly before top coating.*

### Theoretical Coverage:

Apply at 400-500 sq. ft./gal. to achieve

3.0-4.0 mils Wet Film

Thickness

1.0-1.2 mils Dry Film

Thickness

*When calculating working coverage, allow for application losses, texture and porosity of surface, application technique, etc.*

### PRECAUTIONS/LIMITATIONS

- Please refer to Safety Data Sheets.
- Allow final coat to dry 48 hours before use.
- Allow 7 days to reach full cure.
- Apply only if air, surface and material temperatures remain 50° F or above during application and drying.



# CLEARGUARD

## SATIN INTERIOR WB FLOOR REFINISHER

### V365

DESIGNER SERIES  
INTERIOR  
SATIN  
V365  
CLEARGUARD WB  
FLOOR FINISH

### **SURFACE PREPARATION**

Surfaces must be dry, clean and free of dust, dirt, grease, wax, oil, chalk, rust or any other contaminants that may prevent proper adhesion. New wood should be stained and sealed before finishing. Previously stained, painted or varnished surfaces should be thoroughly sanded and dusted clean before applying finish. Two coats are recommended. Sand lightly and dust between coats.

**Warning! If you scrape, sand or remove old paint, you may release lead dust. Lead is toxic. Exposure to lead dust can cause serious illness, such as brain damage, especially in children. Pregnant women should also avoid exposure. Wear a NIOSH-approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the national lead information hotline at 1-800-424-LEAD (5323) or log on to [www.epa.gov/lead](http://www.epa.gov/lead).**

### **HALLMAN LINDSAY FINISHING RECOMMENDATIONS**

#### **New Work**

**Stain:** Woodshades Interior Stain Series.

**Sealer (optional):** Spray Kote Sanding Sealer, v372.

**Recoat Surfaces:** May be applied over existing coatings only after sample applications have been made to check the sensitivity of the existing coating. Surfaces must be properly prepared if sensitivity or lifting occurs.

### **APPLICATION**

Stir thoroughly before use. Shaking will cause Air bubbles to form in finish. Apply by brush, roller, airless, HVLP, or conventional spray. Flow and leveling is best achieved by applying a full, uniform coating and working to a wet edge using overlapping strokes. Surfaces should be dry prior to paint application. Sand lightly between coats with sandpaper or nylon abrasive, not steel wool, and remove any sanding dust. All products are formulated ready for application. If needed, thin sparingly and do not exceed 2oz per gallon. Clean all applicators with water immediately after use.

### **EQUIPMENT REQUIREMENTS**

**HVLP:** Not Recommended

**Roller:** Swivel Head Floor Roller, with Flocked Foam Cover

**Brush:** 100% Nylon or Synthetic Blend